REFERENCE CARD

START - Quick Print

OPTION - Quick print in inverse
(Hold C down at same time to center)

SELECT - Color Rotation

N - Normal Printing
Type N then a size
Graphics 8&E: 1-8
Graphics 9: 1-4
Then hit START for normal or OPTION for inverse (not Graphics E) to print
(Hold down C to center)
ESC aborts the print out.
TAB changes the cursor shade
RETURN exits this mode

S - Sideways Printing
Same as above

ESC - Converts Graphics 8, 7.5 (E), & 9 screens (when the picture is displayed on the screen)
- Aborts the print out and returns to Magniprint II+ (when printing a picture)

SPACE BAR & L - Load A New Screen

SPACE BAR & T - Touch-Up

OPTION - to flash cursor
Joystick Trigger - to draw
E - to enter erase mode
D - return to draw mode
RETURN - to exit Touch-Up mode

SPACE BAR & X - Insert Text
(Graphics modes 8 and 7.5)

Joystick - to position cursor
Joystick Trigger - fine vertical motion
TAB - change cursor shades
CTRL-TAB then 1, 2, 3, or 4 - Change text size
RETURN - exit this mode

SPACE BAR & P - Poster Printing

Graphics 7.5 - Allows shade selection. After selection, press START to print

Other Graphic Modes - START to print normally
- OPTION to print inverse

P - Pauses printing

SPACE BAR & C - Change spacing

Spacing 1-9

Spacing of 2 is normal on most printers

E - toggles in and out of EXPANDED mode. Spacing 2 in EXPANDED is normal on some newer printers

Space Bar - to exit